# BME3321:Introduction to Microcontroller Programming

Topic 7: Universal Synchronous/Asynchronous Serial Communications – USART peripheral

Assist. Prof. Dr. İsmail Cantürk

Mastering STM32 (ch8)


STM32F407 reference manual (ch 30)

### Some terminologies

To exchange data between two (or even more) digital devices, we have two alternatives:

Parallel communication: The number of physical communication lines equal to the size of the each data packet (e.g., eight independent lines for a byte (eight bits) transmission).






# Some terminologies

Serial communication: Transmission of bits one by one.





Device

Cable

#### **Serial Communications**

There is a really high number of serial communication protocols and hardware interfaces available in the electronics industry.

One of this is the Universal Synchronous/Asynchronous Receiver/Transmitter interface, also simply known as USART.

Almost every microcontroller provides at least one UART peripheral. Almost all STM32 MCUs provide at least two UART/USART interfaces. E.g., STM32F4 has six USART peripherals.

MCUs can use USART peripheral to communicate with computers, other MCUs, or different digital systems.

#### **Serial Communications**

When the information flows between two devices via USART, both devices (transmitter and the receiver) have to agree on the **timing** (i.e., how long it takes to transmit each bit)

Synchronous transmission: the transmitter and the receiver share a common clock generated by one of the two devices (usually the device that acts as the master of this interconnection system).




Figure 1: A serial communication between two devices using a shared clock source

The transmission speed and duration are defined by the clock:

When the master device starts clocking the dedicated line, it means that it is going to send a sequence of bits.

Its frequency determines how fast we can transmit a single byte on the communication channel.

#### **Serial Communications**

Asynchronous transmission: It does not use a dedicated clock line. Both devices involved in data transmission agree on how long it takes to transmit a single bit and when to start and finish transmission.




Figure 2: The timing diagram of a serial communication without a dedicated clock line

The idle state (that is, no transmission occurring) is represented by the high signal.

Transmission begins with a START bit, which is represented by the low level. The negative edge is detected by the receiver and 1.5 bit periods after this the sampling of bits begins.

The transmission is ended by a STOP bit, which last 1.5 bits.

Eight data bits are transmitted. The least significant bit (LSB) is typically transmitted first. An optional parity bit is then transmitted (for error checking of the data bits). Often this bit is omitted if the transmission channel is assumed to be noise free.

#### Difference between a USART and a UART

USART: A Universal Synchronous Receiver/Transmitter interface is a device able to transmit data serially using two I/Os, one acting as transmitter (TX) and one as receiver (RX), plus one additional I/O as one clock line.

UART: a Universal Asynchronous Receiver/Transmitter uses only two RX/TX I/Os.





Figure 3: The signaling difference between a USART and a UART

# Some other communication terminologies: Full Duplex, Half Duplex, and Simplex



#### **USARTs of STM32F4**

Table 148. USART mode configuration<sup>(1)</sup>

USART modes	USART 1	USART 2	USART 3	UART4	UART5	USART 6
Asynchronous mode	X	X	X	Х	X	X
Hardware flow control	X	X	X	NA	NA	X
Multibuffer communication (DMA)	X	X	X	X	X	X
Multiprocessor communication	X	X	X	X	X	X
Synchronous	X	X	X	NA	NA	X
Smartcard	X	X	X	NA	NA	X
Half-duplex (single-wire mode)	X	X	X	X	X	X
IrDA	X	X	X	X	X	X
LIN	Х	Х	Х	X	X	X

<sup>1.</sup> X = supported; NA = not applicable.

USARTs can be configured to work both in synchronous and asynchronous mode.

UARTs can only work in asynchronous mode.

#### **USARTs**

Like all STM32 peripherals, even the USARTs are mapped in the memory (i.e., peripheral region of the memory mapping).

Check from reference manual.

They are connected to the different buses.

0x4000 5000 - 0x4000 53FF	UART5	
0x4000 4C00 - 0x4000 4FFF	UART4	==8
0x4000 4800 - 0x4000 4BFF	USART3	
0x4000 4400 - 0x4000 47FF	USART2	===
0x4000 4000 - 0x4000 43FF	I2S3ext	
0x4000 3C00 - 0x4000 3FFF	SPI3 / I2S3	
0x4000 3800 - 0x4000 3BFF	SPI2 / I2S2	
0x4000 3400 - 0x4000 37FF	I2S2ext	

## **USART** management with HAL

UART management are done with a C struct *UART\_HandleTypeDef*, which is defined in the following way:

```
typedef struct {
USART TypeDef
                                                                    /* UART registers base address */
                                         *Instance;
UART InitTypeDef
                                                                    /* UART communication parameters */
                                         Init;
                                                                    /* UART Advanced Features initialization parameters */
UART AdvFeatureInitTypeDef
                                         AdvancedInit;
                                                                    /* Pointer to UART Tx transfer Buffer */
                                         *pTxBuffPtr;
uint8 t
                                                                    /* UART Tx Transfer size */
uint16_t
                                        TxXferSize;
                                                                    /* UART Tx Transfer Counter */
uint16 t
                                         TxXferCount;
                                                                    /* Pointer to UART Rx transfer Buffer */
uint8 t
                                         *pRxBuffPtr;
                                         RxXferSize;
                                                                    /* UART Rx Transfer size */
uint16 t
                                                                    /* UART Rx Transfer Counter */
uint16 t
                                         RxXferCount;
                                                                    /* UART Tx DMA Handle parameters */
DMA HandleTypeDef
                                         *hdmatx;
                                                                    /* UART Rx DMA Handle parameters */
DMA HandleTypeDef
                                         *hdmarx;
HAL LockTypeDef
                                                                    /* Locking object */
                                         Lock;
__IO HAL_UART_StateTypeDef
                                                                    /* UART communication state */
                                         State:
IO HAL UART ErrorTypeDef
                                                                    /* UART Error code */
                                        ErrorCode;
} UART HandleTypeDef;
```

Some most important fields of this struct:

**Instance**: is the pointer to the USART descriptor that we are going to use. For example, USART2.

**Init**: is a nested C struct UART\_InitTypeDef, which is used to configure the UART interface.

AdvancedInit: This field is used to configure more advanced UART features like the automatic Baud Rate detection and the TX/RX pins swapping.

**pTxBuffPtr** and **pRxBuffPtr**: these fields point to the transmit and receive buffer respectively.

pTxBuffPtr and pRxBuffPtr are used as source to transmit **TxXferSize** bytes over the UART and to receive **RxXferSize** when the UART is configured in Full Duplex Mode.

TxXferCount, RxXferCount, Lock: these fields are used internally by the HAL.

All the UART configuration activities are performed by using the C struct *UART\_InitTypeDef*, which is defined in the following way:

```
typedef struct {
uint32_t BaudRate;
uint32_t WordLength;
uint32_t StopBits;
uint32_t Parity;
uint32_t Mode;
uint32_t HwFlowCtl;
uint32_t OverSampling;
} UART_InitTypeDef;
```

Some important fields of this struct:

BaudRate: this parameter refers to the connection speed, expressed in bits per seconds. Even if the parameter can assume an arbitrary value, usually the BaudRate comes from a list of well-known and standard values. Not all BaudRates can be easily achieved without introducing communication errors.

Baud rate		Oversampling by 16		Oversampling by 8	
S.No	Desired (Bps)	Actual	%Error	Actual	%Error
2	2400	2400	0	2400	0
3	9600	9600	0	9600	0
4	19200	19200	0	19200	0
5	38400	38400	0	38400	0
6	57600	57620	0.03	57590	0.02
7	115200	115110	0.08	115250	0.04
8	230400	230760	0.16	230210	0.8
9	460800	461540	0.16	461540	0.16
10	921600	923070	0.16	923070	0.16
11	2000000	2000000	0	2000000	0
12	3000000	3000000	0	3000000	0
13	4000000	N.A.	N.A.	4000000	0

Check the reference manual.

WordLength: it specifies the number of data bits transmitted or received in a frame. We can transmit 8 or 9 data bits in a frame. This number does not include the overhead bits transmitted, such as the start and stop bits.

StopBits: This field specifies the number of stop bits transmitted. We can use one or two stop bits to signal the end of the frame.

Parity: it indicates the parity mode. Parity is a very simple form of error checking. When parity is enabled, the computed parity is inserted at the MSB position of the transmitted data (9th bit when the word length is set to 9 data bits; 8th bit when the Word length is set to 8 data bits).

Parity Mode	Description
UART_PARITY_NONE	No parity check enabled
UART_PARITY_EVEN	The parity bit is set to 1 if the count of bits equal to 1 is odd
UART_PARITY_ODD	The parity bit is set to 1 if the count of bits equal to 1 is even

Mode: it specifies whether the RX or TX mode is enabled or disabled.

<b>UART Mode</b>	Description			
UART_MODE_RX	The UART is configured only in receive mode			
UART_MODE_TX	The UART is configured only in transmit mode			
UART_MODE_TX_RX	The UART is configured to work bot in receive an transmit mode			

HwFlowCtl: it is for RS232 communication.

OverSampling: when the UART receives a frame from the remote peer, it samples the signals in order to compute the number of 1 and 0 constituting the message. This part can be 8 or 16.

For example, if the over sampling field is 16, 16 samples are taken for each frame bit.

### **UART Communication in Polling Mode**

To transmit a sequence of bytes over the USART in polling mode the HAL provides the function:

```
HAL_UART_Transmit(UART_HandleTypeDef *huart, uint8_t *pData, uint16_t Size, uint32_t Timeout);
```

huart: it is the pointer which identifies and configures the UART peripheral;

pData: is the pointer to an array, with a length equal to the Size parameter, containing the sequence of bytes we are going to transmit.

Timeout: is the maximum time, expressed in milliseconds, we are going to wait for the completion of transmitting .

### **UART Communication in Polling Mode**

To receive a sequence of bytes over the USART in polling mode the HAL provides the function:

```
HAL_UART_Receive(UART_HandleTypeDef *huart, uint8_t *pData, uint16_t Size, uint32_t Timeout);
```

huart: it is the pointer which identifies and configures the UART peripheral;

pData: is the pointer to an array, with a length equal to the Size parameter, containing the sequence of bytes we are going to receive.

Timeout: is the maximum time, expressed in milliseconds, we are going to wait for the completion of receiving.

# **UART Communication in Interrupt Mode**

USART peripheral may generate IRQs depending on different situations. The source of these interrupts include both IRQs related to data transmission and to communication errors.

Table 6: The list of USART related interrupts

Interrupt Event	<b>Event Flag</b>	<b>Enable Control Bit</b>
Transmit Data Register Empty	TXE	TXEIE
Clear To Send (CTS) flag	CTS	CTSIE
Transmission Complete	TC	TCIE
Received Data Ready to be Read	RXNE	RXNEIE
Overrun Error Detected	ORE	RXNEIE
Idle Line Detected	IDLE	IDLEIE
Parity Error	PE	PEIE
Break Flag	LBD	LBDIE
Noise Flag, Overrun error and Framing Error in multi buffer communication	NF or ORE or FE	EIE

# **UART Communication in Interrupt Mode**

However, STM32 MCUs are designed so that all these IRQs are bound to just one ISR for every USART peripheral. It is up to the user code to analyze the corresponding event Flag to infer which interrupt has generated the request.




Figure 11: How the USART interrupt events are connected to the same interrupt vector

### **UART Communication in Interrupt Mode**

To transmit a sequence of bytes in interrupt mode, the HAL defines the function:

```
HAL_UART_Transmit_IT(UART_HandleTypeDef *huart, uint8_t *pData, uint16_t Size);
```

To receive sequence of bytes in interrupt mode, the HAL defines the function:

```
HAL_UART_Receive_IT(UART_HandleTypeDef *huart, uint8_t *pData, uint16_t Size);
```

huart: it is the pointer which identifies and configures the UART peripheral.

pData: it is the pointer to an array, with a length equal to the Size parameter, containing the sequence of bytes we are going to transmit.